

SUDwell™

The Resin Bonded Slab Company

Top Tips to Achieving a Good Finish

Power blast down old surfaces such as a concrete, block paving and tarmac then seal with primer to stop contamination and dirt migrating through the resin bound mix when floating.

Always clean out your mixer when using different colour stone batches otherwise one colour can migrate into the first couple of mixes of the other. If burning out your mixer and tools, either thoroughly clean the burnt residue with cleaning fluids such as solvent/xylene. Then either run the mixer with a couple of dry bags of aggregate for 15 minutes and dispose of or mix your aggregate and resin as normal and spread as a base layer, this way the dirty contaminated mix will never be seen under the next clean mix.

It is always a good idea to never mix batches. i.e. you have a few bags left from your last job or a job completed some months earlier with a new fresh order of aggregate, every batch can be different.

Every batch of aggregate may be different to the previous: either being mined from further into the mine or from a completely different mine or country.

Never leave your bags of aggregate out in the rain or sun as this can produce moisture which will change the colour of the aggregate.